

User's Manual

Beltweigher OJ436

Before Ver 4.5



PART OF VENDIG AB

Tel. +46 247 13657

e-mail: oj.s@vagsystem.se

www.vagsystem.se

FRONT PANEL OPERATION.

September 2004 Page 1 of 6

The belt weigher has three different passwords to access

PASS 001: Calibrations
PASS 002: Configuration
PASS 003: Maintenance

To gain access to either data area from the working display operate the **SELECT** key until the indicator shows **PASS**. Use the **▲** and **◻** keys to show the appropriate password number; then operate **ENTER** to show the first parameter in the area accessed. Use **SELECT** to index through the parameters.

Data entry:

Having selected the parameter you wish to adjust operate **ENTER** at which point the first digit flashes on/ off.

Use the **▲** **◻** and **◻** keys to modify the digits until the required setting is obtained. Operate **ENTER** again to steady the value.

To exit a data area operate **ENTER** at the last parameter in every password – **EXIT**.

TARE OF THE BELT WEIGHER.

To perform a dynamic tare without entering the password, operate the **CLEAR** and **SELECT** keys (**CLEAR** first) for 3 seconds. Note that the belt must run empty!!!

DEAD RANGE is lit when the flow rate is less than the **DEAD RANGE** setting.

The internal dynamic zero is adjusted every 30 seconds by 0.01% of the Loadcell Capacity (LC) during periods within dead range with the belt running empty.

An ***** symbol is displayed when the tacho signal is lost i.e. belt stopped.

READING OF THE RESETTABLE TOTAL:

Operate **TOTAL** and the current value is shown in the display, operate **CLEAR** to reset.

The non-resettable total:

Operate **SELECT** to read the total.

Operate **FLOW** to return to flow rate.

This total *is* resettable within **PASS 003** with **ENTER - CLEAR - ENTER** key sequence.

CALIBRATION.

September 2004 Page 2 of 6

The flow rate display and the rate of totalisation are determined by the Calibration Factor, parameter **CF** in password 001. The calibration may be checked and if necessary automatically adjusted i.e. the weigher is re-calibrated as follows:

- Enter the parameter **DC**, Dynamic Calibration, in password 001.
- Operate **CLEAR**.
- Pass known weight over weigher (or quantity of material that can be subsequently weighed).
- Operate **CLEAR** to stop the totalisation process.
- Check that the totalised reading corresponds to the known test weight. Otherwise operate **ENTER** and modify the readout to the test weight value and operate **ENTER** to complete the calibration.

You can also execute the calibration as follows:

- Check the parameter **0.000TN**, you will find it in password 003, operate **CLEAR** to reset.
- Pass known weight over weigher (or quantity of material that can be subsequently weighed).
- Check the totalised reading in password 003, use the calculation below to determine the divergence:

$$\frac{\text{Weigher minus Test weight} \times 100}{\text{Test weight}} = \text{Divergence in \%}$$

e.g.
$$\frac{12\,300\text{kg} - 12\,600\text{kg} \times 100}{12\,600\text{kg}} = -2,38\%$$

If the weigher needs to be re-calibrated, the **Calibration Factor** must be directly adjusted in the parameter **CF**.

Enter the parameter **CF** and adjust the current value with the same percentage as the divergence. *How? See side 1, Data Entry.*

e.g.
$$\text{CF} = 40.00 - 2,38\% = 39.05$$

Password 003, this section provides a facility for monitoring the input signals for the loadcell and tachometer.

T: **Non-resettable total**, which may be reset with Enter - Clear - Enter key sequence.

HZ: **Tacho speed**, multiply by 0,0236 to read the beltspeed in m/ s.
e.g. 76 x 0,0236 = 1,8 m/s.

ADC: **Analog to Digital Convertor** output 0-65,535 divided by 4. This is the weight input signal before any tare or calibration have been made i.e. the raw weight reading.

LCS: Load Cell Signal, the weight input signal displayed in Kg before any tare or calibration adjustments have been made. It is the gross weight applied to the loadcell within the range defined by the LC setting.

These values should be wrote down in the **list of specifications** after montage of the belt weigher, should any malfunction occur at some time, check the current values and compare with those written down.

Display	M/S
85	2,0
80	1,9
76	1,8
73	1,7
68	1,6
64	1,5
60	1,4
55	1,3
50-52	1,2
46	1,1
42	1,0

OVERVIEW OF THE PARAMETERS.

September 2004 Page 4 of 6

Password 001

TS = Tacho Simulator, set to 0 with external tachometer.
FL = Flow, used to determine at what level DR parameter below should be set.
DR = Dead Range, specifies the minimum flow rate below which readings are ignored.
TP = Tare Pulses.
DT = Dynamic Tare.
DC = Dynamic Calibration.
CF = Calibration Factor.
CC = Calibration Counter.
PSET = Password Set, determines the password code for access to this section (001).
EXIT = Exit, allows the user to return to normal display mode upon operation of ENTER.

Password 002

P436 = Model Version, with affix -, A and U.
LC = Load Cell Capacity.
WF = Weigher Filter.
SF = Speed Filter
PG = Pre-Gain, (7).
IN = Increment (Display).
UP = Update Rate (mS, Display).
DDP = Display Decimal Place.
SDP = Static Decimal Place.
TONS Yes = tonnes, No = kg.
WO = Yes/ No Weight Output Pulse.
OP = Output Pulse.
TR = Trip, determines the flow level at which the T1 relay output switches to on.

*SP = Span, maximum flow reading. *Analogue Parameters, only when PR436 = A.
*AZ = Analogue Zero.
*AR = Analogue Range.

*BR = Baud Rate. *PR436 = S/M
*ADDR = For communication.

PSET = Password Set, determines the password code for access to this section (002).
EXIT = Exit, allows the user to return to normal display mode upon operation of ENTER

Password 003

T = Non-Resettable Total, which may be reset with Enter - Clear - Enter key sequence.
HZ = Tacho Speed.
ADC = Analogue to Digital Convertor.
LCS = Load Cell Signal.
0.000 TN = Total to 3 decimal places, used for test weighing.
PSET = Password Set, determines the password code for access to this section (003).
EXIT = Exit, allows the user to return to normal display mode upon operation of ENTER

WIRING DIAGRAM.

September 2004 Page 5 of 6

OJ436: Colour:

+VE	Red	
+SE	Grey	
+IN	Green	
-IN	Yellow	Loadcell
-SE	Pink	
-VE	Blue	

+V	Brown/ white	
----	--------------	--

SG	Black	Tacho
----	-------	-------

0V	Violet	
----	--------	--

T0	1	Resettable Total
----	---	------------------

T0	2	
----	---	--

T1	1	Productiontime
----	---	----------------

T1	2	
----	---	--

A1+	Analogue output	
-----	-----------------	--

G -		
-----	--	--

E		
---	--	--

N	85-264ac	
---	----------	--

L		
---	--	--

+	9-36dc	
-		

Connectionbox: Colour: 10-p contact:

1	Red	1	
2	Grey	8	
3	Green	2	
4	Yellow	3	
5	Pink	10	9 = Shield
6	Blue	4	

+V	Brown/ white	5	
----	--------------	---	--

SG	Black	6	
----	-------	---	--

0V	Violet	7	
----	--------	---	--

Loadcell/ box: Colour: 1250:

1	Blue	Green
2	Green	Blue
3	White	Red
4	Red	White
5	Grey	Brown
6	Black	Black

Tacho/ box: Färg:

+V	Brown
SG	Black
0V	Blue

Out of Range

This condition occurs if the load cell input signal is outside the full scale input range as defined by the amplifier pre-gain (parameter **PG**), or if the tacho input is above 500Hz.

Display shows '**ADC-SAT+**'

Indicates that the input is outside the range in the positive direction.

Display shows '**ADC-SAT-**'

Indicates that the input is outside the range in the negative direction.

Display shows '**OV SPEED**'

Indicates that the tacho input is outside the 500Hz range.

Failures

Although unlikely, the following types of equipment failure are possible. In all cases the unit may be returned to us for repair.

No response

No indication or response of any kind. Possibly a supply circuit failure. A soldered-in PCB (Printed Circuit Board) fuse may need replacing as a result. Alternatively the fuse failure could be the only failure.

Display shows '**REGFAULT**'

This occurs if the load cell supply is overloaded due to wiring or load cell faults, or if the internal 10V supply regular has failed.

Display shows '**SENSE ER**'

This occurs if the sense voltage (between the +SE and the -SE load cell terminals) has varied by more than 0.3V with respect to the internal value which was stored at the last Tare operation.

Display shows '**ERR nnn**' where **nnn** Fault Code Number

This indicates that a microprocessor fault has occurred. It may help to report the Fault Code Number to us when returning the unit for repair.

Lost Pass Numbers: Restore Factory Settings

In the event of the passwords being lost the original factory default setting of 1, 2 and 3 can be reloaded by holding down the SELECT and ENTER keys for approximately 30 seconds (operate ENTER key first). After this time the display changes to read RESET. The password number will have been restored to 1, 2 and 3.

TEST WEIGHING FOR OJ436

CUSTOMER: _____ POSITION: _____

WEIGHER: _____ LOCATION: _____

NOTES: _____

Diff % =
$$\frac{(\text{belt weigher} - \text{reference scale}) \times 100}{\text{reference scale}}$$
 If the belt weigher registers less weight than the reference scale, decrease the CF with the diff. %

Test No.	1	2	3	4	5
CF					
OJ436 Kg					
Reference Kg					
Diff. Kg					
Diff. %					

Reference scale used: _____

Date: _____

Completed by: _____

OJ:s VågsystemAB
Tallskogsvägen 9
793 35 Leksand

☎ 0247-136 57

✉ oj.s@vagsystem.se